



Maintenance & Servicing Board System

(in accordance with EN 15312)

Daily / Weekly Check (Visual Routine Inspection)

A daily check is required in cases of:

heavy use, vandalism, coastal locations, air pollution, older equipment.

Otherwise, a weekly check is sufficient.

- Do the moving parts (especially access doors and their locks) work properly?
- Shake test: are all boards firmly in place, without any play?
- Are all screws and rivets still present?
- Are the warning signs fully legible and undamaged?
- Are the nets and net fixings undamaged and complete?
- Is the equipment clean?
- Visual inspection: are there any loose parts? Are there any sharp edges? What is the general condition of the SoccerGround®?
- Important: replace missing parts and fixings with original SoccerGround® spare parts!

Monthly Check

- Visual inspection: are there any visible fractures or cracks on any components?
- Visual/manual check (by hand only, gently, WITHOUT a wrench): are all bolted connections tight?

Weather-Dependent Check

- If a roof net is fitted, it should be cleared of leaves and snow regularly or, if heavy snowfall is expected, removed for the winter.
- The pitch should not be used during thunderstorms.

Annual Check (Operational Inspection)

- All items from the "Daily / Weekly Check" checklist
- Visual inspection: are there any visible fractures or cracks on any components?
- Visual/manual check (by hand only, gently, WITHOUT a wrench): are all bolted connections tight?



Maintenance & Servicing Board System

(in accordance with EN 15312)

Notes

- Missing, damaged or worn components and/or assemblies may only be replaced with original SoccerGround® spare parts.
- The use of third-party components (including screws, etc.) voids all legal and warranty claims.
- Braided cord can be used to repair the net. Open ends must be sealed (e.g. with a lighter), and each patched cord must be secured with a double knot.

Warnings

- Access to the SoccerGround® is only permitted for children aged three and over!
- Goals and nets are not suitable as climbing frames!
- Finger rings and other jewelry can get caught in the nets. Risk of injury!

Contact

If your SoccerGround has any missing parts or damage, we will be happy to offer you the right spare parts or an on-site repair.

Please contact: info@soccerground.de